



2141 and 2141S Air Impact Wrench Parts List

Item	Part Description	Part Number	Item	Part Description	Part Number
1	Cylinder	2141-3	26	Inlet Retainer Clip	2141-57
2	Front End Plate	2141-11	27	Inlet Parts Kit	2141-K303
3	Front Rotor Bearing	R38P-606	28	Inlet Bushing Seal	R4-210
4	Rear Rotor Bearing	2131-97	29	Tilt Valve Spring	2131-51
• 5	Vane Packet (set of 6 Vanes)	2141-42-6	30	Tilt Valve	2141-302
6	Rotor	2141-53	31	Tilt Valve Seat	2141-303
7	Rear Rotor Bearing Retainer	2131-6	32	Tilt Valve Seat Support	2141-306
• 8	Motor Gasket	2141-283	33	Tilt Valve Seat Retainer	SML8-24
9	Anvil Assembly	2141-A626	• 34	Trigger Assembly	2141-A93
• 10	Socket Retainer	908B5-918	35	Trigger O-ring	---
• 11	Socket Retainer O-ring	AF120-289	36	Reverse Valve Assembly	2141-A329
12	Hammer Case Screw (4)	2141-638	37	Reverse Valve O-ring (top)	---
	Hammer Frame Assembly	2141-A703	38	Reverse Valve O-ring (bottom) (blue)	---
13	Hammer Frame	2141-703	39	Button Kit	2141-K75
14	Hammer Pin (2)	2141-704	40	Forward Button	---
15	Hammer (2)	2141-724	41	Reverse Button	---
16	Hammer Case Assembly	2141-727	42	Power Management Dial	2131-A249
17	Hammer Case Bushing	2141-641	43	Power Management Dial Seal	---
18	Grease Fitting	D0F9-879	44	Inlet Clip Removal Tool	2131-322
• 19	Hammer Case Gasket	2141-36	45	Silencer (4) (2141S only)	2131S-310
20	Housing Assembly	2141-A40	*	Grease (1 lb) (for external lubrication of the impact mechanism)	115-1LB
21	Housing Label	2141-99	*	Grease (for lubrication when disassembling and assembling the impact mechanism)	
22	Warning Label	WARNING-2-99		1 lb	105-1LB
23	Nameplate			8 lb	105-8LB
	for 2141	2141-301			
	for 2141S	2141S-301	*	Protective Cover	2141-P32
	Inlet Bushing Assembly	2141-D565	*	Grease Gun	R000A2-228
24	Inlet Bushing	2141-565			
25	Inlet Bushing Screen	5RA-61			